

Hp1 sd card error when changing batteries

Posted by Youngmeezy - 03 Nov 2017 05:07

I charge a second set of batteries externally as my cord is bad. when i change the batteries and power on, i get the sd card error, and when I plug it into computer, i'm forced to re format the card. any ideas what would cause this?

=====