

Sentinel bug report? Removing CTCSS

Posted by centauri61032 - 26 Aug 2011 13:16

OK, I am trying to edit my favorites list, and remove the CTCSS tones on some channels. I pick a channel to edit, and click on the Audio Options field (which currently contains a CTCSS code). The audio options box opens, and I change the Audio Type to 'All' and hit OK. This appears to clear out the CTCSS field. I save the file, and close out the edit mode. But when I go back and review, the changes did not get saved. The original CTCSS code is still there.

Am I doing something wrong, or is there a bug in the file save?

=====